

# Champion Garage Door Repair

## Garage Door Torsion Spring - Wire Size Chart

10 Coils		20 Coils		Your Wire Size
Inches	Centimeters	Inches	Centimeters	
1 15/16"	4.88	3 7/8"	9.75	0.192
2"	5.08	4"	10.16	0.200
2 1/16"	5.26	4 1/8"	10.52	0.207
2 3/16"	5.55	4 3/8"	11.11	0.218
2 1/4"	5.72	4 1/2"	11.45	0.225
2 3/8"	5.95	4 11/16"	11.90	0.234
2 3/8"	6.02	4 3/4"	12.04	0.237
2 7/16"	6.19	4 7/8"	12.38	0.243
2 1/2"	6.35	5"	12.70	0.250
2 5/8"	6.67	5 1/4"	13.34	0.262
2 3/4"	6.93	5 1/2"	13.87	0.273
2 13/16"	7.19	5 5/8"	14.38	0.283
2 7/8"	7.34	5 3/4"	14.68	0.289
2 15/16"	7.49	5 7/8"	14.99	0.295
3 1/16"	7.79	6 1/8"	15.57	0.306
3 1/8"	7.94	6 1/4"	15.88	0.312
3 3/16"	8.12	6 3/8"	16.23	0.319
3 5/16"	8.41	6 5/8"	16.81	0.331
3 7/16"	8.73	6 7/8"	17.46	0.343
3 5/8"	9.21	7 1/4"	18.42	0.362
3 3/4"	9.53	7 1/2"	19.05	0.375
3 15/16"	10.00	7 7/8"	20.01	0.393
4 1/16"	10.32	8 1/8"	20.63	0.406
4 7/32"	10.71	8 7/16"	21.43	0.421
4 5/16"	10.93	8 5/8"	21.87	0.430
4 3/8"	11.11	8 3/4"	22.23	0.437
4 17/32"	11.51	9 1/16"	23.02	0.453
4 5/8"	11.72	9 1/4"	23.44	0.461
4 11/16"	11.90	9 3/8"	23.81	0.468
4 7/8"	12.45	9 3/4"	24.89	0.490
5"	12.70	10"	25.40	0.500
5 5/16"	13.49	10 5/8"	26.98	0.531
5 5/8"	14.29	11 1/4"	28.58	0.562
6 1/4"	15.88	12 1/2"	31.75	0.625